


Applicable to:

- EcoFlow STREAM Microinverter (used as the example product in this guide)
- EcoFlow STREAM Pro
- EcoFlow STREAM Ultra



- Connect the cable to the PV terminal of your STREAM device. The actual number of cables depends on your solar connection needs.
- Never connect the leads of a solar panel to different PV terminals (e.g., negative to PV1- and positive to PV2+) to prevent short circuits.
- To reconnect the PV terminals, use a PV wrench and pull the connectors apart.

